



Wood Street Canal Planting Plan

New Westminster, BC

Planting Zone 1 – MSE Flex Wall Above HWM (~ 135m², density = ~3 plants/bag)

Scientific Name	Common Name	Pot Size	Comments
<i>Rosa gymnocarpa</i>	baldhip rose	plugs	Plant evenly throughout
<i>Spiraea douglasii</i>	hardhack	plugs	Plant evenly throughout
<i>Symphoricarpos albus</i>	snowberry	plugs	Plant evenly throughout

Planting Zone 2 – MSE Flex Wall Below HWM (~36m², density = ~3 plants/bag)

Scientific Name	Common Name	Pot Size	Comments
<i>Carex obnupta</i>	slough sedge	plugs	Plant evenly throughout
<i>Juncus effusus</i>	common rush	plugs	Plant evenly throughout
<i>Salix scouleriana</i>	Scouler's willow	live-stakes	Plant evenly throughout

Planting Zone 3 – High Riparian (~ 750m², density = ~2 plants/m²)

Scientific Name	Common Name	Pot Size	Comments
<i>Mahonia nervosa</i>	dull Oregon grape	#1	Plant evenly throughout
<i>Rosa gymnocarpa</i>	baldhip rose	#1	Plant evenly throughout
<i>Symphoricarpos albus</i>	snowberry	#1	Plant evenly throughout
<i>Spiraea douglasii</i>	hardhack	plugs	Plant evenly throughout
<i>Salix scouleriana</i>	Scouler's willow	live-stakes	Plant evenly throughout

*See Revegetation Specifications

